

PARTS LIST



ASSEMBLY

STEP 1: Put the folded frame upside down and extend the legs. One section.









NOTE: Sometimes the second section can be pulled out. Stop and make sure that the correct section is extended.

STEP 2: Flip frame to its feet and expand the frame.





NOTE: When expanding the frame make sure to expand evenly in all directions, so the parts do not skew and get stuck. When fully expanded, make sure it is locked in place.



STEP 3: Place the Roof Panel on top of the frame.



NOTE: Placing the roof at this stage, before fully extending the legs is easier, especially if you have low ceiling.

STEP 4: Extend the legs and adjust to comfortable height.



NOTE: There are four height options to choose from..

STEP 5: Attach the wall panels to the frame using Velcro tie ups attached to the wall.







NOTE: Start at center of frame and work your way around.







NOTE: Wall panels can be joined at the back with Velcro.





NOTE: We provide a Zipper opening for the front entrance.





NOTE: The provided LED light can be simply placed on the frame at a convenient location. Run the cord under the panels and connect to an outlet.