

FlexTee Stand

Assembly Instructions:



FlexTee Stand is a unique universal stand that have many utility options.

It was specifically designed to be used to support acoustic blankets for mobile acoustic treatment solutions, and as a stand for Voice Over Mobile recording studio – VOMO. It can also be used to support light, as light truss.

Unlike other similar stands which are usually only 3 feet wide, the Flex Tee stand has a “wingspan” of 6.5 feet (80 inches) and it is also Flexible not only in terms of usage, but also because the arms can be folded forward, which is especially beneficial if the stand is used for blocking Echo and reverb from audio recording either with microphone, or video camera. In its current set up the FlexTee Stand requires some assembly.

1

It comes in a Box:



In a nice Nylon bag:



With Parts wrapped in plastic to keep them nice all the way home!




Take that plastic off to see the new shiny parts:



2

The parts have names:




You can lay them out like this, to make sure you got everything, and see how it all fits together:




3

Start with the first base and line up the second section to go into it:



Now it is time to assemble the arms.

(You can assemble them any time, of course, before or after, your choice.)





1



2



3



Do not overtighten the screws at this point. You need to be able to flex the arms first (or not).



6


NOTE: *the very first time it might feel tight and the arm does not fold. That is because the parts cut very close and the fresh paint makes it tight. Give it a little push and it will be OK. Also please be aware that the arms can only fold forward, and only in one direction.*

And it only folds UP TO 90 degrees




Now Insert the connection pin of the T-bar into the
Top Section of the stand.

(Make sure to unscrew the knob bolt first,
but do not take it all out)




Now that you can flex the arms and put them on the stand – spread the legs:



8

VERY IMPORTANT:

To provide more stability for the stand, put its best leg forward. Because when the arms are flexed in front and there is a blanket on, the center of gravity shifts forward. Positioning the leg in front, will add stability to the whole assembly.



Now the Flex tee stand is assembled and ready to work!

So what is the mini Mic stand pole for?

The mini mic stand pole is included to use the stand with VOMO.

To mount VOMO on the stand – remove the T-bar
and install the mini Mic stand pole instead:



After that VOMO can be mounted
on the Mic Stand Pole

FLEX TEE STAND USE SUGGESTIONS:

As mentioned before the FlexTee stand was designed to work with Acoustic Blankets Producer's Choice to control room acoustics.


It can be used as a portable GOBO, as make shift acoustic vocal booth portable acoustic panel that can be placed at strategic locations and used for example to control reflections on live stage in different venues.

Below we give some suggestions on how to mount acoustic blankets.

To hang the blankets, we supply eight (8) S-hooks. (That is because Producer's choice acoustic blankets have 8 grommets and the FlexTee stand was designed to work with our blankets)

1. Set up the FlexTee stand on the floor and adjust the height, so the T-bar is at your chest level, or whichever level is the most convenient for you to hang the blankets at.

2. Insert the S-hooks:




3. Start hanging blankets from the center – out. This helps to keep the stand balanced.



11

Then attach the blanket to the hooks on the left and the right side and raise the stand with the blankets up to the desired height:





Pin

12

Forward looking leg
for better balance

USAGE EXAMPLES

Reflection filter screen/ Acoustic Shield



Your personal anti-reverberation Castle



14

TWO Stands and TWO blankets –

Portable Video Booth/ Photo booth



15

TWO Stands and TWO blankets –

The flexible arms allow to shield the camera from all sides yet leave the space open for unobstructed filming.

